

NOTES:

- I. FOR ANCHOR BOLT EMBEDMENT LENGTH AND ANCHOR BASE DATA REFER TO APPROPRIATE 800 SERIES STANDARD PLATE.
- 2. ALL ANCHOR BOLTS SHALL BE PLUMB AFTER FOUNDATION INSTALLATION. STEEL TEMPLATE PLATE SHALL BE USED TO SET ANCHOR BOLTS.
- 3. BASE PLATE SHALL BE IN FULL CONTACT WITH ALL FLAT WASHERS.
- 4. ALL ANCHOR BOLT NUTS SHALL BE TIGHTENED USING TURN OF NUT METHOD. (30° min to 45° max turn after snug tight)
- 5. GROUT SHALL NOT BE PLACED BETWEEN THE BASE PLATE AND CONCRETE BASE.
- FOR FOUNDATION DETAILS REFER TO APPROPRIATE 800 SERIES STANDARD PLATE

